




### ATTENZIONE !

Prima di procedere al montaggio , assicurarsi di avere bene compreso quanto indicato dal presente foglio illustrativo .

Il non rispetto dei punti sotto riportati potrebbe compromettere il buon funzionamento della trasmissione e dei cuscinetti in essa contenuti .

- 1) Procedere al montaggio sul veicolo del / dei Supporti per trasmissione ( A ) .
- 2) Posizionare manualmente la trasmissione ed il Supporto ( Cavallotto ) ( B ) utilizzando gli spessori forniti .
- 3) Verificare che la luce libera non superi 1 o 1.5 mm . In caso contrario procedere ad aggiungere o togliere spessori .
- 4) Bloccare il cavallotto ( B ) con la vite e il dado forniti .
- 5) Verificare , dopo aver bloccato la trasmissione , che la stessa giri libera !

### ATTENTION !

*Before the installation , please read very carefully the following points .*

*If the following points are not correctly applied you can create problem to the transmission and the bearings contained in the some shaft .*

- 1) *Assemble on the vehicle the support/s for the transmission ( A ) .*
- 2) *Place manually the transmission and the support ( B ) using the supplied spacers .*
- 3) *Verify that the free space indicated in the above drawing **don't exeed 1 or 1.5 mm** . Otherwise insert or remove the spacers .*
- 4) *Lock the support ( B ) with the supplied bolt and nut .*
- 5) *Verify , once you have locked the transmission , that the same turn free !*